


## ANAGRAMSHOP / DIY PAPER CAMERA / FREE A4 CUTOUT


Print A4 at ACTUAL SIZE / 100%. Dashed = cut. Dotted = fold.

Decorative photo holder, not a real camera or automatic photo printer.


### A / FRONT / 95 x 70 mm




### C / PHOTO CARD / 55 x 70 mm



### B / BACK / 95 x 70 mm



### D / TWO SIDE SPACERS



### E / BOTTOM SPACER / 95 x 12 mm



## ASSEMBLY IN 5 STEPS

1. Cut A, B, C, two D strips and E along dashed outlines.
2. Fold D and E lengthwise; glue at side and bottom edges.
3. Join A and B with spacers. Keep the top completely open.
4. Decorate card C and leave part of its top tab visible.
5. Insert and gently pull the photo by hand to reveal it.



SCALE CHECK: this line must measure exactly 50 mm.

Original anagramshop template / Personal use / Not affiliated with Polaroid.

## Build your paper camera photo holder

These diagrams explain the fold, glue and pull-out photo. Not to scale.

### 1 CUT THE PARTS

Cut A, B, C, both side strips and the bottom strip.




### 2 FOLD THE SPACERS

Fold the strips along their dotted center lines.



### 3 GLUE THREE SIDES

Join A and B along the left, right and bottom edges only.



TOP IS OPEN

### 4 INSERT YOUR PHOTO


Draw or attach a small picture to card C; keep a tab visible.



PHOTO OR DRAWING

### 5 GENTLY PULL IT OUT

Insert through the open top and pull the card by hand.



MANUAL SLIDING CARD